



AOC-S3108L-H8iR

User's Guide

Revision 1.0

The information in this User's Guide has been carefully reviewed and is believed to be accurate. The vendor assumes no responsibility for any inaccuracies that may be contained in this document, and makes no commitment to update or to keep current the information in this user's guide, or to notify any person or organization of the updates. **Please Note: For the most up-to-date version of this user's guide, please see our Website at www.supermicro.com.**

Super Micro Computer, Inc. ("Supermicro") reserves the right to make changes to the product described in this user's guide at any time and without notice. This product, including software and documentation, is the property of Supermicro and/or its licensors, and is supplied only under a license. Any use or reproduction of this product is not allowed, except as expressly permitted by the terms of said license.

IN NO EVENT WILL SUPER MICRO COMPUTER, INC. BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL, SPECULATIVE OR CONSEQUENTIAL DAMAGES ARISING FROM THE USE OR INABILITY TO USE THIS PRODUCT OR DOCUMENTATION, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. IN PARTICULAR, SUPER MICRO COMPUTER, INC. SHALL NOT HAVE LIABILITY FOR ANY HARDWARE, SOFTWARE, OR DATA STORED OR USED WITH THE PRODUCT, INCLUDING THE COSTS OF REPAIRING, REPLACING, INTEGRATING, INSTALLING OR RECOVERING SUCH HARDWARE, SOFTWARE, OR DATA.

Any disputes arising between the manufacturer and the customer shall be governed by the laws of Santa Clara County in the State of California, USA. The State of California, County of Santa Clara shall be the exclusive venue for the resolution of any such disputes. Supermicro's total liability for all claims will not exceed the price paid for the hardware product.

FCC Statement: This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the manufacturer's instruction manual, may cause harmful interference with radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case you will be required to correct the interference at your own expense.

California Best Management Practices Regulations for Perchlorate Materials: This Perchlorate warning applies only to products containing CR (Manganese Dioxide) Lithium coin cells. "Perchlorate Material-special handling may apply. See www.dtsc.ca.gov/hazardouswaste/perchlorate".

WARNING: Handling of lead solder materials used in this product may expose you to lead, a chemical known to the State of California to cause birth defects and other reproductive harm.

User's Guide Revision 1.0

Release Date: Oct. 28, 2015

Unless you request and receive written permission from Super Micro Computer, Inc., you may not copy any part of this document.

Information in this document is subject to change without notice. Other products and companies referred to herein are trademarks or registered trademarks of their respective companies or mark holders.

Copyright © 2015 by Super Micro Computer, Inc.
All rights reserved.

Printed in the United States of America

Preface

About this User's Guide

This user's guide is written for system integrators, IT professionals, and knowledgeable end users. It provides information for the installation and use of the AOC-S3108L-H8iR add-on card.

An Important Note to the User

All images and layouts shown in this user's guide are based upon the latest PCB revision available at the time of publishing of this user guide. The add-on card you have received may or may not look exactly the same as the graphics shown in this user's guide.

Returning Merchandise for Service

A receipt or copy of your invoice marked with the date of purchase is required before any warranty service will be rendered. You can obtain service by calling your vendor for a Returned Merchandise Authorization (RMA) number. When returning to the manufacturer, the RMA number should be prominently displayed on the outside of the shipping carton and mailed prepaid or hand-carried. Shipping and handling charges will be applied for all orders that must be mailed when service is complete.

For faster service, RMA authorizations may be requested online (<http://www.supermicro.com/support/rma/>).

This warranty only covers normal consumer use and does not cover damages incurred in shipping or from failure due to the alteration, misuse, abuse or improper maintenance of products.

During the warranty period, contact your distributor first for any product problems.

During the warranty period, contact your distributor first for any product problems.

Conventions Used in the User's Guide

Pay special attention to the following symbols for proper system installation:

Warning: Important information given to ensure proper system installation and to avoid causing damage to the components or causing injury to yourself.



Note: Additional information given for proper system setup.

Important Links

For your system to work properly, please follow the links below to download all necessary drivers/utilities and the user's manual for your server.

- Supermicro product manuals: <http://www.supermicro.com/support/manuals/>
- Product drivers and utilities: <ftp://ftp.supermicro.com>
- Product safety info: http://www.supermicro.com/about/policies/safety_information.cfm
- If you have any questions, please contact our support team at: support@supermicro.com

This manual may be periodically updated without notice. Please check the Supermicro website for possible updates to the manual revision level.

Contacting Supermicro

Headquarters

Address: Super Micro Computer, Inc.
980 Rock Ave.
San Jose, CA 95131 U.S.A.

Tel: +1 (408) 503-8000

Fax: +1 (408) 503-8008

Email: marketing@supermicro.com (General Information)
support@supermicro.com (Technical Support)

Web Site: www.supermicro.com

Europe

Address: Super Micro Computer B.V.
Het Sterrenbeeld 28, 5215 ML
's-Hertogenbosch, The Netherlands

Tel: +31 (0) 73-6400390

Fax: +31 (0) 73-6416525

Email: sales@supermicro.nl (General Information)
support@supermicro.nl (Technical Support)
rma@supermicro.nl (Customer Support)

Web Site: www.supermicro.nl

Asia-Pacific

Address: Super Micro Computer, Inc.
3F, No. 150, Jian 1st Rd.
Zhonghe Dist., New Taipei City 235
Taiwan (R.O.C)

Tel: +886-(2) 8226-3990

Fax: +886-(2) 8226-3992

Email: support@supermicro.com.tw

Web Site: www.supermicro.com.tw

Table of Contents

Preface

About this User's Guide	3
An Important Note to the User.....	3
Returning Merchandise for Service.....	3
Conventions Used in the User's Guide.....	3
Important Links.....	4
Contacting Supermicro.....	5

Chapter 1 Introduction

1-1 Overview	1-1
1-2 About this Add-on Card.....	1-1
1-3 Key Features.....	1-1
1-4 Supermicro Motherboard Support.....	1-2

Chapter 2 Hardware Components

2-1 Add-On Card Image and Layout.....	2-1
2-2 Major Onboard Components.....	2-1
2-3 SAS 3.0 Ports and CPLD JTAG Header	2-2
SAS Ports.....	2-2
CPLD JTAG Header	2-2
2-4 LED Indicators.....	2-3
SAS Activity LED.....	2-3
SAS Fault LED.....	2-3
System Heartbeat LED	2-3

Chapter 3 Installation

3-1 Static-Sensitive Devices.....	3-1
Precautions	3-1
3-2 Before Installation	3-2
3-3 Installing the Add-on Card	3-2

Chapter 4 Configuring the Avago MegaRAID Setting

4-1 RAID Minimum Drive Requirements.....	4-1
4-2 Using the Avagp MegaRAID Configuration Utility.....	4-2
4-3 The Avago MegaRAID Main Screen.....	4-3
4-4 VD Mgmt (Virtual Drive Management).....	4-4
4-5 PD Mgmt (Physical Drive Management).....	4-7
4-6 Ctrl Mgmt (Control Management)	4-8

4-7	Properties	4-9
4-8	Foreign View	4-10
Chapter 5 MegaRAID Controller Firmware Update Procedures		
5-1	Flashing Firmware Using MegaCLI under DOS	5-11
5-2	Flashing Firmware Using MegaRAID Storage Manager	5-13
Chapter 6 MegaRAID CacheCade Configuration		
6-1	Enabling MegaRAID CacheCade Support	6-1
	Minimum System Configuration Requirements	6-1
	CacheCade Key Activation	6-2
6-2	Configuring the CacheCade RAID Settings and Creating a Drive Group	6-4
6-3	Creating a CacheCade - SSD Caching Virtual Drive	6-7
6-4	Configuring Virtual Drive Settings	6-9
6-5	Enabling SSD Caching Support on a Virtual Drive	6-10

Notes

Chapter 1

Introduction

1-1 Overview

Congratulations on purchasing your add-on card from an acknowledged leader in the industry. Supermicro products are designed with the utmost attention to detail to provide you with the highest standards in quality and performance.

1-2 About this Add-on Card

The Supermicro AOC-S3108L-H8iR is the most technological-advanced, cost-effective, and reliable SAS MegaRAID adapter in today's market. With the Avago 3108 SAS controller, eight 12Gb/s SAS connectors, and a low-profile PCI-E Gen.3 x8 slot built in, this add-on card offers high-performance connectivity with enormous storage capacity to meet the growing needs of enterprise server platforms.

With the optional Supercap/TFM unit built-in, the AOC-S3108L-H8iR supports 2GB DDR3 on-card cache at a speed of 1866 MHz (maximum), providing cached data protection during catastrophic system failures.

In addition, the embedded Avago SAS 3108 I/O processor offers optimal RAID performance and a PCI-Express host interface for increased I/O bandwidth. The AOC-S3108L-H8iR adapter delivers an intelligent and robust RAID solution to the market. For more information regarding product support or updates, please refer to our website at <http://www.supermicro.com/products/accessories/addon/aoc-s3108l-h8ir.cfm>.

1-3 Key Features

The key features of this add-on card include the following:

- Avago SAS 3108 8-port PCI-E SAS-3.0 controller
- Eight internal SAS3 ports w/two mini SAS HD connectors
- Hardware RAID 0, 1, 5, 6,10, 50, and 60 supported
- Onboard hardware I/O processor
- Supports up to 240 physical devices

- 2GB DDR3 ECC Unbuffered on-card cache with a speed of up to 1866MHz for cached data protection
- Advanced array configuration and management utilities
- Automatically-negotiated PCI-E link widths
- Port-independent auto-negotiation
- Supports SSP, SMP, STP and SATA protocols
- Optional Supercap/CacheVault BTR-TFM8G-LSICVM02 (Installation kit PN=MCP-240-001270N)
- Supports MegaRAID Storage Manager software
- Enlarged venting hole mounting bracket for improved airflow
- Supports 1.5, 3.0, 6.0 and 12.0 Gb/s SAS and 3.0 & 6.0 Gb SATA data transfer rates
- OS support: Windows 2012, 2k8 64/32-bit, RedHat Enterprise, and SUSE Linux
- Support Fastpath(Free) and Cachecade (AOC-CHCD-PRO2-ESW)
- Power consumption: 23 watts
- Operation temperatures: 0°C to 55°C (32°F to 131°F)
- Dimensions 2.71" (H) x 6.6" (L) (68.83cm (H) x 167.64cm (L))

1-4 Supermicro Motherboard Support

This add-on card supports the following motherboards:

- X10SDV-TLN4F
- X10SRA-F
- X10SRD-F
- X10SRG-F


- X10SRH-CF
- X10SRH-CLN4F
- X10SRI-F
- X10SRL-F
- X10SRW-F
- X10DAi
- X10DAC
- X10DAX
- X10DAL-i
- X10DRC-T4+
- X10DRC-LN4+
- X10DRI-T4+
- X10DRI-LN4+
- X10DRD-iNTP
- X10DRD-LTP
- X10DRFF-C
- X10DRFR-T
- X10DRT-P
- X10DRG-Q
- X10DRH-C
- X10DRH-iT
- X10DRI-T

- X10DRL-CT
- X10DRL-i
- X10DRT-L
- X10DRT-LIBQ
- X10DRT-LIBF
- X10DRU-i+
- X10DRW-E
- X10DRW-N
- X10DRX


Chapter 2

Hardware Components

2-1 Add-On Card Image and Layout



The AOC-S3108L-H8iR Image



The AOC-S3108L-H8iR Image

2-2 Major Onboard Components

The following major components are installed on the AOC-S3108L-H8iR:

Major Components					
No	Component Name	No	Component Name	No	Component Name
A	3108 SAS CTRL	1	SAS ports 0~3	4	LED1: Activity LED
B	Onboard Buzzer	2	SAS ports 4~7	5	LED6: Fault LED
C	PCI-E 3.0 x8 slot	3	CPLD JTAG (header)	6	D13: System Heartbeat LED

2-3 SAS 3.0 Ports and CPLD JTAG Header


SAS Ports

Eight SAS ports, supported by the Avago 3108 SAS controller, are located on the add-on card. SAS 0-3 and SAS 4-7 support SAS 3.0 connections. See the table below for pin definitions.

SAS 3.0 Pin Definitions	
Pin#	Signal
1	Ground
2	SATA_TXP
3	SATA_TXN
4	Ground
5	SATA_RXN
6	SATA_RXP
7	Ground

CPLD JTAG Header

A 6-pin CPLD JTAG header, located at JP8, is used to scan complex-programmable logic devices. Connect a cable to JP8 for CPLD JTAG scan to enhance system security and data integrity. See the layout below for the location.



1. SAS Ports 0~3
2. SAS Ports 4~7
3. CPLD JTAG Scan

2-4 LED Indicators

SAS Activity LED

The SAS Activity LED is located at LED1 on the add-on card. When LED1 is blinking, the SAS connections supported by the Avago 3108 controller are active. See the table below for more information.

SAS Activity LED Status	
Color/State	Definition
Green: Blinking	SAS: Active

SAS Fault LED


LED6 is used to indicate if a SAS failure has occurred. When LED6 is on, an error has occurred to on-card SAS connections. See the table below for more information.

SAS Fault LED Status	
Color/State	Definition
Red: On	SAS Error(s) detected

System Heartbeat LED

The System Heartbeat LED is located at D13 on the add-on card. When D13 is blinking, the system is functioning normally. See the table below for more information.

System Heartbeat LED Status	
Color/State	Definition
Green: Blinking	System: Normal
Off or Red	System: Disabled or Failed



1. SAS Activity LED
2. SAS Fault LED
3. System Heartbeat LED

Notes

Chapter 3

Installation



Note: Your system came with the AOC--S3108L-H8iR adapter pre-installed as a part of an integrated solution. We do not recommend that any part of your system components be removed and re-installed. However, if you do need to remove or re-install a system component, including this add-on card, please follow the instructions below to ensure proper system setup. Also, be sure to remove the power cord first before adding, removing or changing any hardware components to avoid damaging the system or components.

3-1 Static-Sensitive Devices

Electrostatic Discharge (ESD) can damage electronic components. To avoid damaging your add-on card, it is important to handle it very carefully. The following measures are generally sufficient to protect your equipment from ESD.

Precautions

- Use a grounded wrist strap designed to prevent static discharge.
- Touch a grounded metal object before removing the add-on card from the antistatic bag.
- Handle the add-on card by its edges only; do not touch its components, or peripheral chips.
- Put the add-on card back into the antistatic bags when not in use.
- For grounding purposes, make sure that your system chassis provides excellent conductivity between the power supply, the case, the mounting fasteners and the add-on card.

3-2 Before Installation

To install the add-on card properly, be sure to follow the instructions below.

1. Power down the system.
2. Remove the power cord from the wall socket.
3. Use industry-standard anti-static equipment (such as gloves or wrist strap) and follow the instructions listed on Page 3-1 to avoid damage caused by ESD.
4. Familiarize yourself with the server, motherboard, and/or chassis documentation.
5. Make sure that your operating system includes the latest updates and hot-fixes.

3-3 Installing the Add-on Card

Follow the steps below to install the add-on card into your system.

1. Remove the server cover and, if necessary, set aside any screws for later use.
2. Remove the add-on card slot cover. If the case requires a screw, place the screw aside for later use.
3. Position the add-on card in the slot directly over the connector, and gently push down on both sides of the card until it slides into the PCI connector.
4. Secure the add-on card to the chassis. If required, use the screw that you previously removed.
5. Attach any necessary external cables to the add-on card.
6. Replace the chassis cover.
7. Plug the power cord into the wall socket, and power up the system.

Chapter 4

Configuring the Avago MegaRAID Setting

This chapter provides instructions on how to configure MegaRAID settings for the Avago 3108 SAS controller. If you do not wish to configure MegaRAID settings, skip this section and go directly to OS installation.

4-1 RAID Minimum Drive Requirements

The AOC-S3108L-H8iR add-on card supports up to 240 HDD with RAID 0, 1, 5, 6, 10, 50 and 60. Use the table below to determine the minimum number of hard drives needed to set up a RAID environment.

RAID	Minimum Hard Drives
RAID 0	2
RAID 1	2
RAID 5	3
RAID 6	3
RAID 10	4 (Two RAID 1 arrays)
RAID 50	6 (Two RAID 5 arrays)
RAID 60	6 (Two RAID 6 arrays)

4-2 Using the Avagp MegaRAID Configuration Utility

Follow the steps below to start the Avago MegaRAID Configuration Utility.

1. Power on the system.
2. Press <Ctrl><R> to enter the Avago MegaRAID Configuration Utility when the following screen displays.

```
AVAGO MegaRAID SAS-MFI BIOS
Version 6.25.03.0 (Build April 10, 2015)
Copyright(c) 2015 AVAGO Technologies
HA -0 (Bus 3 Dev 0) AVAGO 3108 MegaRAID
FW package: 24.9.0-0022

Battery Status: Missing
PCI Slot Number: 0

ID LUN VENDOR PRODUCT REVISION CAPACITY
-- -- -
0 0 AVAGO AVAGO 3108 MegaRAID 4.290.00-4536 2048MB
0 0 HITACHI HUC103030CSS600 A540 286168MB
1 0 HITACHI HUC103030CSS600 A540 286168MB
0 0 AVAGO Virtual Drive RAID1 285632MB

1 Virtual Drive(s) found on the host adapter.
1 Virtual Drive(s) handled by BIOS

Press <Ctrl><R> to Run MegaRAID Configuration Utility
-
```

4-3 The Avago MegaRAID Main Screen

On the top of the Avago MegaRAID main screen is a list of configurable menus. Press <Ctrl><N> or <Ctrl><P> to select the menu. The main screen includes the following menus:

- VD Mgmt (Virtual Drive Management)
- PD Mgmt (Physical Management)
- Ctrl Mgmt (Controller Management)
- Properties
- Foreign View

```
AVAGO 3100 MegaRAID BIOS Configuration Utility 5.10-0700
UD Mgmt PD Mgmt Ctrl Mgmt Properties
Virtual Drive Management
[-] AVAGO 3100 MegaRAID(Bus 0x03, Dev 0x00)
  [-] Drive Group: 0, RAID 1
    [-+] Virtual Drives
    [-+] Drives
    [-+] Available size: 0.000 KB
    Hot spare drives
Controller:
Drive Groups: 1
Virtual Drives: 1
Drives: 2
F1-Help F2-Operations F5-Refresh Ctrl-N-Next Page Ctrl-P-Prev Page F12-Ctrl
```

Avago MegaRAID Configuration Utility Main Screen

4-4 VD Mgmt (Virtual Drive Management)

When you enter the MegaRAID Configuration Utility, the VD Mgmt is the first menu screen that displays, as shown below. This screen provides information about the configuration of controllers, drive groups, and virtual drives. The right panel of the screen displays the information about the selected device. To select a submenu item, use the up arrow and down arrow keys. Use the right arrow to open a submenu, and the left arrow to close a submenu.

```
AVAGO 3108 MegaRAID BIOS Configuration Utility 5.10-0700
VD Mgmt | PD Mgmt | Ctrl Mgmt | Properties
Virtual Drive Management
[-] AVAGO 3108 MegaRAID(Bus 0x03, Dev 0x00)
  [-] Drive Group: 0, RAID 1
    [-] Virtual Drives
    [-] Drives
    [-] Available size: 0.000 KB
    [-] Hot spare drives
Controller:
Drive Groups: 1
Virtual Drives: 1
Drives: 2
F1-Help F2-Operations F5-Refresh Ctrl-N-Next Page Ctrl-P-Prev Page F12-Ctrl
```


VD Mgmt (Virtual Management) Menu Screen

Move the cursor to select the controller and press <F2>, as shown below. Press <Enter> to create new virtual drives when the following screen displays.




Note You can use the up arrow and down Arrow keys here to select enabled commands, which are highlighted in white, such as “Create Virtual Drive” or “Clear Configuration”.

Press <Enter> for the RAID level selection when the screen below shows. This screen also allows you to select parameters of the new virtual drive using the up arrow, down arrow, or <Tab> keys.



Use the up arrow and down arrow keys to select the RAID level, as shown below, and press <Enter>.



Note The corresponding RAID level(s) will display based on the number of hard drives connected to the selected controller.

4-5 PD Mgmt (Physical Drive Management)

Press <Ctrl><N> or <Ctrl><P> to select the PD Mgmt menu, as shown below. This screen provides information about hard drives connected to the selected controller. The right panel of the screen shows the information about the selected device.

Slot	Type	Capacity	State	DG	Vendor
---:--:00	SAS	278.937 GB	Online	00	HITACHI
---:--:01	SAS	278.937 GB	Online	00	HITACHI

PAGE-1
Enclosure Info
Vendor: AVAGO
Enclosure ID: 252
Enclosure Location: Unknown
Enclosure Model: SGPIO

F1-Help F2-Operations F5-Refresh Ctrl-N-Next Page Ctrl-P-Prev Page F12-Ctrl

PD Mgmt (Physical Management) Menu Screen

To select a device, use the up arrow, down arrow or <Tab> keys and press <F2>. Press <Enter> to perform a command, such as rebuilding a failed drive, locating a drive, or making a drive offline, as shown below.


PAGE-1

- Rebuild
- Copyback
- Locate
- Place drive Online
- Place drive Offline
- Make Global HS
- Remove Hot Spare drive
- Make JBOD
- Make unconfigured good
- Prepare for Removal

F1-Help F2-Operations F5-Refresh Ctrl-N-Next Page Ctrl-P-Prev Page F12-Ctrl

4-6 Ctrl Mgmt (Control Management)

Press <Ctrl><N> or <Ctrl><P> to select the Ctrl Mgmt menu, as shown below. This menu provides information about the settings of the selected controller. On this screen, use the up arrow, down arrow or <Tab> keys to move the cursor. To apply changes, navigate to APPLY and press <Enter>.



Navigate to Next and press <Enter> to open the second screen, as shown below. The following screen allows you to view and changes settings, such as the link speed or the power save.



4-7 Properties

Press <Ctrl><N> or <Ctrl><P> to select the Properties menu, as shown below. This menu provides read-only information about the properties of the selected controller.

```

AVAGO 3100 MegaRAID BIOS Configuration Utility 5.10-0700
UD Mgmt PD Mgmt Ctrl Mgmt Properties
Properties
Product Name      : AVAGO 3100 MegaRAID
Controller Status : Optimal
Serial No        :
ROC Temperature  : 61 Celsius
Package          : 24.9.0-0022
FW Version       : 4.290.00-4536
BIOS Version     : 6.25.03.0_4.17.00.00_0x060E0300
Boot Block Version : 3.07.00.00-0002
Battery status   : Missing
Security Capable : No
Controller ID    : 0
PCI Bus          : 0x03
PCI Device       : 0x00
PCI Function     : 0x00
PCI Slot ID      : 0x00
Metadata Size    : 512 MB
Data Protection Support : Yes
Data Protection Enabled : Yes
Emergency Spare  : Unconfigured Good & Global Hot Spare

[ Page:01 ]
< Next >
F1-Help F5-Refresh Ctrl-N-Next Page Ctrl-P-Prev Page F12-Ctrl

```

Navigate to Next and press <Enter> to open the second screen to view more properties, as shown below. To go back to the first screen, navigate to Prev (Previous) and press <Enter>.

```

AVAGO 3100 MegaRAID BIOS Configuration Utility 5.10-0700
UD Mgmt PD Mgmt Ctrl Mgmt Properties
Properties
Emergency For SMARTer : Disabled
Power Saving on Unconfigured Drives : Enabled
Power Saving on Hot Spare : Enabled
Drive Standby Time : 30 min
Copyback SSD on Smart Error: Yes
Memory Size : 2048 MB

< Prev >
[ Page:02 ]
F1-Help F5-Refresh Ctrl-N-Next Page Ctrl-P-Prev Page F12-Ctrl

```

4-8 Foreign View

Press <Ctrl><N> or <Ctrl><P> to select the Foreign View menu, as shown below. This menu provides information about the foreign configurations, such as drive groups, virtual drives, physical drives, and hot spare drives. Also, this menu allows you to import or clear the foreign configurations. Please note that the Foreign View menu displays only when a foreign configuration has been connected to the controller.

```
AVAGO 3108 MegaRAID BIOS Configuration Utility 5.10-0700
UD Mgmt PD Mgmt Ctrl Mgmt Properties Foreign View
Foreign Config View
[-] AVAGO 3108 MegaRAID (Bus 3, Dev 0)
  [-] Drive Group: 0, Raid 0 (Foreign)
    [-] Virtual Drives
      ID: 0, 557.875 GB
    [-] Drives
      ---:00: Online: 278.937 GB(Foreign)
      ---:01: Online: 278.937 GB(Foreign)
    Hot spare Drives
Foreign Config Preview
Drive Group 0:
Virtual Drives: 1
Drives: 2
F1-Help F2-Operations F5-Refresh Ctrl-N-Next Page Ctrl-P-Prev Page F12-Ctrl
```

Foreign View Menu Screen

Chapter 5

MegaRAID Controller Firmware Update Procedures

This chapter provides instructions on how to flash MegaRAID controller firmware. Please visit our website at www.supermicro.com for more information about firmware/utilities downloads.

5-1 Flashing Firmware Using MegaCLI under DOS

1. You need the MegaCLI utility and ROM file (smc3108.rom) to flash the MegaRAID firmware.
2. Boot from the USB key and use the following command syntax as shown below, or run the batch file.

```
megacli -adpfwflash -f <filename.rom> -a0
```

```
C:\AUAG0\3108\FW\4290~1.00->megacli -adpfwflash -f smc3108.rom -a0
DOS/32A -- Protected Mode Run-time Version 7.2
Copyright (C) Supernar Systems, Ltd. 1996-2002
DOS/32A warning (9004): mouse initialization failed

Adapter 0: LSI 3108 MegaRAID
Vendor ID: 0x1000, Device ID: 0x005D

Package version on the controller: 24.6.0-0023
Package version of the image file: 24.9.0-0022
Download Completed.
Flashing image to adapter...
Adapter 0: Flash Completed.
Please reboot the system for the changes to take effect

Exit Code: 0x00
C:\AUAG0\3108\FW\4290~1.00->
```

3. The screen below shows an example of flashing the MegaRAID firmware using the batch file (smc3108.bat).

```

C:\AVAGO\3108\FW\4290~1.00->smc3108.bat

***   LSI SAS3108-MR controller FW Flash   ***
*                                           *
*                                           *
*   Flash SMC LSI SAS3108-MR firmware   *
*                                           *
*                                           *
*****
DOS/32A -- Protected Mode Run-time Version 7.2
Copyright (C) Supernar Systems, Ltd. 1996-2002
DOS/32A warning (9004): mouse initialization failed

Adapter 0: LSI 3108 MegaRAID
Vendor ID: 0x1000, Device ID: 0x005D

Package version on the controller: 24.6.0-0023
Package version of the image file: 24.9.0-0022
Download Completed.
Flashing image to adapter...
Adapter 0: Flash Completed.
Please reboot the system for the changes to take effect

Exit Code: 0x00

C:\AVAGO\3108\FW\4290~1.00->

```

4. Reboot the system and check the firmware version in the controller banner during boot up as shown below.

```

AVAGO MegaRAID SAS-MFI BIOS
Version 6.25.03.0 (Build April 10, 2015)
Copyright(c) 2015 AVAGO Technologies
HA -0 (Bus 3 Dev 0) AVAGO 3108 MegaRAID
FW package: 24.9.0-0022

Battery Status: Missing
PCI Slot Number: 0


ID LUN VENDOR PRODUCT REVISION CAPACITY
-----
0 0 AVAGO AVAGO 3108 MegaRAID 4.290.00-4536 2048MB
1 0 HITACHI HUC103030CSS600 A540 286168MB
0 0 HITACHI HUC103030CSS600 A540 286168MB
0 0 AVAGO Virtual Drive RAID1 285632MB

```


5-2 Flashing Firmware Using MegaRAID Storage Manager

You need the MegaRAID Storage Manager software and ROM file (smc3108.rom) to flash the MegaRAID firmware. Follow the steps below to use the MegaRAID Storage Manager software on the following platforms: Microsoft Windows operating system and Linux operating system.

1. Open the MegaRAID Storage Manager application.
2. Right-click on the Avago 3108 controller to be updated, and select the Update Controller Firmware menu option as shown below.




MegaRAID Storage Manager Screen on a Microsoft Windows Operating System




MegaRAID Storage Manager Screen on a Linux Operating System

3. Press the **Browse** button to search for new firmware.
4. Select the new MegaRAID controller firmware as shown below.
5. Click **OK** to continue.




MegaRAID Storage Manager Screen on a Microsoft Windows Operating System




MegaRAID Storage Manager Screen on a Linux Operating System

6. Check **Confirm** in the dialog box and click **Yes** to continue, as shown below.




MegaRAID Storage Manager Screen on a Microsoft Windows Operating System




MegaRAID Storage Manager Screen on a Linux Operating System

7. Do not reboot the system until the following screen displays.
8. Click **OK** once the firmware update is completed as shown below.




MegaRAID Storage Manager Screen on a Microsoft Windows Operating System




MegaRAID Storage Manager Screen on a Linux Operating System

9. Reboot the system and check the firmware version using the MegaRAID Storage Manager application as shown below.



MegaRAID Storage Manager Screen on a Microsoft Windows Operating System



MegaRAID Storage Manager Screen on a Linux Operating System

Chapter 6

MegaRAID CacheCade Configuration

This chapter provides instructions on how to configure MegaRAID CacheCade settings in the Windows environment. Please refer to our website at www.supermicro.com for information on firmware/utilities downloads.


6-1 Enabling MegaRAID CacheCade Support

Minimum System Configuration Requirements

You will need to have the following items pre-installed in your system before configuring MegaRAID CacheCade settings.

1. Minimum of two hard drives
2. AOC-S3108L-H8iR add-on card
3. A PCI-E add-on card
4. Avago S3108 MegaRAID utility
5. A license key for MegaRAID CacheCade (to be purchased from Supermicro)

- After adding all HDDs you want to use to create a drive group to the list, click on **Create Drive Group** to create a CacheCade drive group as shown below.




- From the pull-down submenu, select the RAID setting you want to configure and click **Next** to assign the selected RAID setting to all HDDs included in the drive group list.

6-3 Creating a CacheCade - SSD Caching Virtual Drive

To create a SSD caching virtual drive, please follow the instructions below.

1. From the MegaRAID Storage Manager menu, select **Physical** by clicking on it.
2. From the pull-down menu, select **AVAGO 3108 MegaRAID** by clicking on it.
3. From the available drive list on the left, select the drive to create a virtual drive by double-clicking on it.
4. Double-click on **Create CacheCade™ - SSD Caching Drive Group**.
5. Enter an SSD Caching VD (Virtual Drive) name in the field.
6. Select the desired Write Policy from the pop-up menu.
7. Click **Create Virtual Drive** to create a virtual drive.
8. Repeat the steps 4-6 and click **Update Virtual Drive** to create multiple virtual drives to form a drive group.
9. Once you have created desired virtual drives, click **Next**.



10. To remove a virtual drive from a virtual drive group, select the drive to remove and click on **Remove Virtual Drive**.
11. To cancel the deletion, click on **Cancel**.
12. To proceed to the next step to configure the virtual drive settings, click **Next**.



13. The following screen will display to indicate the status of the virtual drive that you've just created. Review the status of the virtual drive.




14. After reviewing the status of the virtual drive as shown above, click **Back** to make changes as needed, and click **Finish** to complete virtual drive creation.


6-4 Configuring Virtual Drive Settings

To configure the settings for a virtual drive, please follow the instructions below.

1. From the MegaRAID Storage Manager menu, select **Logical** by clicking on it.
2. From the Virtual Drive(s) pull-down menu, select the **Virtual Drive** you want to configure by clicking on it.
3. From the pop-up menu, select the setting you want to use by clicking on it.



4. A dialogue box will display to warn you that a setting of the selected virtual drive will be changed. Click **Confirm** and **Yes** for the virtual drive to use the new setting(s).
5. Click **No** to use the old setting.



(Disclaimer Continued)

The products sold by Supermicro are not intended for and will not be used in life support systems, medical equipment, nuclear facilities or systems, aircraft, aircraft devices, aircraft/emergency communication devices or other critical systems whose failure to perform be reasonably expected to result in significant injury or loss of life or catastrophic property damage. Accordingly, Supermicro disclaims any and all liability, and should buyer use or sell such products for use in such ultra-hazardous applications, it does so entirely at its own risk. Furthermore, buyer agrees to fully indemnify, defend and hold Supermicro harmless for and against any and all claims, demands, actions, litigation, and proceedings of any kind arising out of or related to such ultra-hazardous use or sale.